



1

UPPER HINGE ASSEMBLY KIT

- KIT#: K0227
- 13200.00 V-Cam w/ Bushing
- 18794.00 Bagged Fasteners - Steel
- 18795.00 Bagged Fasteners - Wood
- 18796.00 Proline Kit
- 18705.00 Cover
- QTY: _____

1

NOTCHED BOTTOM LEAF FOR USE W/ 3" JAMB GUARD KIT

- RH KIT#: K0208
- 100-6052 RH Bottom Leaf
- 170-02053 Lock Nut (3)
- 170-02200 Screw (3)
- LH KIT#: K0209
- 100-6053 LH Bottom Leaf
- 170-02053 Lock Nut (3)
- 170-02200 Screw (3)
- QTY: _____

2

3" X 9" JAMB GUARD

- KIT# : K0181
- 13237.00 Jamb Guard
- 18794.00 Bagged Fasteners - Steel
- 18795.00 Bagged Fasteners - Wood

3" X 18" JAMB GUARD

- KIT# : K0183
- 13239.00 Jamb Guard
- 18794.00 Bagged Fasteners - Steel
- 18795.00 Bagged Fasteners - Wood
- QTY: _____

3

REPLACEMENT GASKET KIT W/ WELD PLATES

- SINGLE KIT#: K0447
- a 13016.00 1-1/2" Gasket (8')
- b 13254.00 Top Seal (6')
- c 10641.00 1" Gasket (8')
- d 10642.00 1/2" Gasket (4')
- PAIR KIT#: K0375
- a 13016.50 1-1/2" Gasket (8')
- b 13254.00 Top Seal (6')
- c 10640.00 1" Gasket (8')
- d 10642.00 1/2" Gasket (4')
- QTY : _____

3

REPLACEMENT GASKET KIT W/O WELD PLATES

- SINGLE KIT#: K0445
- a 10641.00 1" Gasket (8')
- b 13254.00 Top Seal (6')
- c 10641.00 1" Gasket (8')
- d 10642.00 1/2" Gasket (4')
- PAIR KIT#: K0228
- a 10641.00 1" Gasket (8')
- b 13254.00 Top Seal (6')
- c 10640.00 1" Gasket (8')
- d 10642.00 1/2" Gasket (4')
- QTY : _____

PROLINE S & 600SEC REPLACEMENT KITS				
SCALE: N/A	MATERIAL: N/A			ITEM NUMBER: N/A
REV #: 2	DWG BY: RTM	DATE: 10/28/19	ECN: N/A	